



5. Final Assembly

Written By: REA



Step 1 — Threaded Inserts



- We need to install 2 threaded inserts to allow the top hull to be fixed into place.

Step 2 — Installing Top Cap



- Place the Top Cap onto the Bottom Cap.
- Use 3 x M3 x 12mm Socket Head Cap Screws to fix the caps together.