



## 2 - Attaching the Motor Mounts

Written By: REA



## INTRODUCTION

Your ROV Motor and Propeller Kit comes with three bilge pump motors, three PVC motor mounts and three propellers with attachments for each. The propellers need to be secured to the motors at the end of the motor mount. Loctite will help to secure the propellers onto the motor and keep them from falling off when moving through the water. To attach your propellers to your motors, follow the instructions found here:

## Step 1 — 2 - Attaching the Motor Mounts



- The motors are attached to the PVC frame with motor mounts. The motor mounts may or may not be pushed over the motor when you receive the kits. If they are not, push the motor mount over the motor.
- Align the motor mount with the logo facing towards the larger half of the motor.
- ⓘ Note: If the PVC motor mount does not quite fit, remove the label sticker on the motor.
- ⓘ If it is too loose, add some tape underneath the motor mount.